

## Compressor Operation Decanting

Key holders: Compressor Leaders & Compressor Safety Officer

A key holder will be needed to open the cupboard.

**Whenever you go down to the compressor you must have the radios on.**  
The person going downstairs should take the ear-piece if it is available.

If available put tape across the steps leading down to the pool to protect members of the public. The tape needs to be breakable in case of a fire.

**DO NOT block the route with cylinders!!**

There is a light in the cupboard. When the cupboard is open, switch on the light!! If batteries are low, tell the Compressor Safety Officer, who will replace them.

1. Ensure that the valves on the board upstairs have been closed
2. Open up the air bank cylinders (valves on top open clockwise)
3. Open up safety valve above air bank
4. Check the pressure on the gauge on the board
5. Attach the tank to be filled (**after checks have been completed**)
6. Close purge valve
7. Open cylinder
8. Open valve slowly

Fill all tanks that have tags (if time)

Once all tanks are filled:

1. Close valves on board
2. Close valves on cylinders (valves on top close anti-clockwise)
3. Open valves on board to vent air in hoses
4. Close safety valve above two tanks
5. Leave valves open on board

**When purging pipes, ensure that you are holding onto the hose you are emptying. Otherwise it will dance around all over the place, potentially causing damage or harm.**

If you notice a leak, inform one of the Compressor Leaders or the Compressor Safety Officer IMMEDIATELY

If filling cylinder banks, note you can also fill tanks on the panel upstairs.